

# SPACES4KIDS

## HEALTH AND SAFETY WARNINGS/CARE AND USE INSTRUCTIONS FOR: ROOM/ACTIVITY DIVIDER SCREENS

Please read these instructions before using your product and retain them for future reference:

Parts/ labour guarantee (10 years from date of purchase) excludes fair normal wear and tear in use indoors, excludes outdoor use and customer damage.

SUPPLIED IN COMPONENT FORM FOR SELF ASSEMBLY: CORRECTLY ASSEMBLED THE SCREENS ARE ROBUST FOR USE IN BUSY DAY CARE SETTINGS.

ADDITIONAL COMPONENTS MAY REQUIRED PLEASE CONTACT US OR YOUR SUPPLIER.

ON DELIVERY: Please check your goods, if you have any immediate problems contact your retailer or us.

No returns accepted after 7 days. No returns accepted unless by prior arrangement. NO RETURNS ONCE PRODUCT HAS BEEN ASSEMBLED

**Component list (per single screen).** 4 x tubes (equal length for squares, 2 long and 2 short for rectangles)  
1 x screen centre panel  
4 x corners: a) 2 x "Slotted corners" (4 halves); b) 2 x "Plain corners" (4 halves)  
**(per Set)** 1 x double-edged flexible slide screen connector per two screens.

**Assembly: 1)** Select the individual components above. **2)** Lay them out as photograph 1 below. Slotted corners = top. Plain corners = bottom (fit first). **3)** Follow sequence shown. Slide tubes onto grey runners, through elastic loops. Push corners in fully to hilt. **CORNERS WITH MISSING GUIDE PINS ARE OK. HOLD THE CORNER HALVES TOGETHER AND PUSH THEM INTO THE SHAPED TUBES**



**TO FINISH: 1)** PULL UP ON THE TOP TUBE STRETCHING THE ELASTIC TO FIT THE TOP TWO CORNERS EACH IN TURN INTO THE TOP OF THE TWO UPRIGHT TUBES.  
2) Add legs to a single screen to use it on its own, or add them to either end of a chain.



**To Join One Screen To The Next:**

SLIDE THE CONNECTOR STRIP DOWN BETWEEN TWO SCREENS AND LEAVE PERMANENTLY FITTED.

**FOR EXTRA RIGIDITY BETWEEN SCREENS:-** SHORTEN CONNECTOR STRIP BY 50–60MM & CLIP IN A DOUBLE CLAW CLIP (AT TOP). MOVE SCREEN TO DESIRED ANGLE. IN LONG CHAINS OF 8 -12 OR MORE SCREENS, THE ADDITION OF CLIP ON LEGS BETWEEN EVERY FOUR SCREENS MAY BE REQUIRED




**FOR BEST STABILITY ALWAYS ZIG ZAG OR CURVE THE SCREENS, SETTING ONE AT A DIFFERENT ANGLE TO THE NEXT. EXTRA COMPONENTS OR SCREENS WILL BE NEEDED IF YOU WANT TO USE SCREENS IN A STRAIGHT LINE**




Screens "Z" fold to store



Other accessories (purchase separately):



**Z4020/ST: Connector Leg (between screens);**



**Z4000/WALL Wall Brackets (Pair)**

- Z4000/CW Double-ended clips/hinges (blue):- use min. 3 per pair of Big Screen, Rectangle and Small Square.
- Z4020/HDLG: Pair Heavy duty feet (wooden) for zigzag screen set up (MDF wood. Not suitable for outdoor/wet/damp areas).
- Z4020/ST: Single Connector Leg. Plastic Base: 500mm tall ply wood. With clips on both sides to deploy screens in a straight line
- Z4000/WALL: Pair of Wall Brackets (not suitable for use outdoors)



**Z4000/CW: Pack of Clips:      Z4020/HDLG: Heavy Duty Legs, (Pair, end, Z4020ST between); Matching mats & seating (see your retailer or [www.spaces4kids.co.uk](http://www.spaces4kids.co.uk))**

### Frequently asked questions

Q: Can I use the screens outside?

A: Your set is shower-proof (Z4020/HD Legs ARE NOT) so when you use your screens outside take care to make sure it is on dry surfaces and out of the wind. You may find Z4020/ST legs with waterproof plastic base are best, you may also need to peg your set to the ground (pegs and guy ropes not supplied) if conditions are windy.

Q: Some of the pieces are missing, what should I do?

A: Contact your retailer or us (01777 869044) and we will send you the missing piece. You can also ask for any other help on this number.

Q: Why are the centre panels flexible?

Flexibility means shock absorption and extra protection in the event of an accidental fall against a screen. The plastic components have rounded edges for the same reason.

Q: My screens seem unstable? Is this wrong?

A: Yes it is wrong. Correctly assembled and correctly joined screens are stable and are suitable for use in most settings. Please call us 01777 869044 and we'll go through the assembly with you on the 'phone to check that you haven't made a mistake and determine if you need some extra components.

Q: How to I turn my two Landscape panels into two Portrait panels

A: Use our double claw clips, you will need at least 3 in between each pair of screens. Additional clips are available at [www.spaces4kids.co.uk](http://www.spaces4kids.co.uk)

#### Specifications and Health and Safety Information

**SELECTING A LOCATION FOR YOUR SCREENS/SETS: PERFORM A RISK ASSESSMENT WITH A SUITABLY QUALIFIED PERSON. ALWAYS SUPERVISE PLAY & LOCATE WHERE CHILDREN WILL NOT BE AT RISK FROM TRIP HAZARDS, ROUGH/SHARP OBJECTS OR HAZARDOUS FALLS E.G. DOORS, RADIATORS, CORNERS OF WALLS, WINDOWS, STAIRS/STEPS, PEDESTRIAN TRAFFIC, MACHINERY, CLEANING/OFFICE/FIRE EQUIPMENT, FURNITURE. DAMAGED PARTS INCLUDING MIRRORS SHOULD BE REPLACED IMMEDIATELY.**

All materials made from EN71 approved materials. Fire retardant to BS5867 Part 2 Type B Curtain and Drape. Print: printed with eco-solvent inks. Parts and labour repair and replacement guaranteed for 10 years from date of purchase for use in normal circumstances. Contains no small parts to cause a choking hazard. Plastic Tube: White recyclable PVC contains 50% recycled plastics. Plastic fittings: premium grade polypropylene. Connector strip: phthalate free flexible PVC. Flexible runner: phthalate free flexible PVC. Sewn with EN 71 approved thread. Mirror plastic centre panels from 1.5mm hammer tough impact resistant safety plastics. NOTE THE HAZARDS POSED BY REFLECTED SUNLIGHT on polished/mirrored surfaces which can dazzle and damage eyes, and in certain circumstances can also provide an ignition source, burning skin or combustible materials, for this reason among others we limit our recommendations on the use of products with mirrors outdoors and do not extend the guarantee to outdoor use.

CARE AND CLEANING: For best cleaning results wipe clean with non-abrasive proprietary household cleaners or dilute bleach solutions, thoroughly dry. Do not use abrasive creams or ammonia based cleaners. CLIP ON LEGS: Do not wet the clip on legs, clean only with furniture polish. CLIP ON LEGS USE OUTSIDE:- coat/paint exposed unlaminated edges of legs with 3 coats of marine quality clear varnish.

**[www.Spaces4Kids.co.uk](http://www.Spaces4Kids.co.uk), by Lifetime Education Ltd:**

**Telephone: 01777 869044: Fax 01777 869048: Email: [info@spaces4kids.co.uk](mailto:info@spaces4kids.co.uk)**

**Unit 3 Aurillac Business Park, Aurillac Way, Hallcroft Industrial Estate, Retford. Notts. DN22 7PX**

**\*Product adaptations for special needs: \*Soft play and ball pools: \* Space planning, room division and activity areas: \* Soft furniture: \* Mats and rest mats.**